



INSTRUCTIONS:

1. Cut template on the dashed line
2. Fit the template on the snorkel and make sure all the holes are accurate
3. Now fit template to vehicle as indicated
4. Drill holes as indicated
5. File the hole until the snorkel fits
6. Fit snorkel to position
7. Do not overtighten bolts

*REMEMBER, THIS TEMPLATE IS A GUIDE ONLY. MAKE SURE OF THE POSITION OF THE HOLES BEFORE YOU DRILL.*